

P.S. FILM PERFOR

Description

Very thin, PVC-free material for Cad-Cut® applications.

The circular perforation allows transpiration, giving at the same time a decorative, special effect.

:Adhesive polyester backing.

Basic Information

Due to the many different base materials available on the market, the following heat transfer instructions are given as guideline only:

Temperature: 150°C

Time: 15"

Pressure: medium

Application Instructions

- 1) Cut the material **in reverse**
- 2) Weed the exceeding material (for an easier weeding, we suggest to leave the cut material on a hot surface – 60/70°C – for a few seconds)
- 3) Place the material on the garment with its polyester support
- 4) Heat apply
- 5) Remove polyester backing **hot**

Suitable for

Cotton, polyester, poly-cotton blends.

Not suitable for treated and dyed garments (sublimation inks)

Washing: (wait 24h after the heat transfer)

60°C Max. – do not use bleach or other aggressive chemical agents

Dry-cleaning : no

Tumble drier : yes

N.B. : all information given in this sheet are based on our experience

We recommend to always perform a test before starting standard production

The product meets the Italian and Ue regulations relating to its proper use.

This document can be subject to variations. Updated versions are available on our website www.siser.it.

For further information, please contact our Sales Office. Thank you.

SISER s.r.l.

V.LE DELLA TECNICA n. 18 – 36100 VICENZA ITALY

TEL. +39 0444 287960 - FAX +39 0444 287959 - E-mail: info@siser.it - www.siser.it

R.E.A. VI 171856 VI – Reg. Imp. VI n. 14971 - Cap. Soc. € 103.300 i.v. – Partita IVA 01591490246

